

5-Port USB 3.0 Hub

User Manual

CH 10 L



Package Contents:

5 in 1 USB 3.0 Hub

USB Type B Cable (1m/3.3ft)

12V 2A Power Adapter (1.2m/4ft)

User Manual



How to Use the USB Hub?

1. Use the DC power adapter to connect the hub to a power outlet.
2. Use the USB 3.0 type B cable to connect the hub to your computer.
3. It's now ready to connect and charge your devices.

*To achieve maximum performance, your computer system, peripherals, cables, and software must all support USB 3.0.



SPECIFICATIONS



Modell: CH 10 L

Output Interface:

Data: 4×USB 3.0, up to 5Gpbs

Charging: up to 2.4A

Material: Aluminum Alloy

Dimensions: 96×52×24mm (L×W×H)


Cable Length: 1 m




Usage Tips

1. For maximum performance, connected devices should not exceed a combined current of 3A. Otherwise, connections may become unstable or disconnect entirely.

For reference, the devices below are often rated as:





Mouse:	100 mA
Camera:	>300 mA
Portable hard disk:	max. 500 mA
USB 3.0 portable hard disk:	max. 900 mA
Keyboard:	max. 500 mA



(1000mA = 1A)

*The ratings above are estimates only. Please check your specific devices' ratings before connecting to the hub.



2. The Charging Port has its own microchip that detects what device is plugged into it through USB pin signals. This enables it to charge each unique device at its fully-intended speed (up to 2.4A) without the risk of harming it. This port can't be used to transmit data.

3. 2.4 GHz wireless devices, such as wireless keyboards and mouse adapters, may not work in close proximity to USB 3.0 devices or hubs. Connecting to a USB 2.0 port is recommended.

4. Some USB 3.0 devices require a direct connection to host USB 3.0 ports, including some USB 3.0 hard disks.



NOTES

Please notice below safety issues:

1. The maximum operating temperature is 40°.
 2. Do not expose to rain, moisture or snow.
 3. Avoid Dropping.
 4. Please use the attachment sold or recommended by the manufacturer.
- 

MAXTRACK



transmedia GmbH
Profilstr. 11
D-58093 Hagen

#18